Section 7 Table of Contents

BMA
Introduction. 7-4
Characteristics 7-5
Plugs 7-6
Jacks ....7-7 to 7-8
Receptacles....7-8 to 7-11
Panel Drilling ....7-11 to 7-12

SMA
Introduction....7-13 to 7-14
Interface. 7-15
Characteristics ....7-16 to 7-17
Straight Plugs ....7-17 to 7-19
Right Angle Plugs ....7-20 to 7-21
Straight Jacks ....7-21 to 7-23
Bulkhead Jacks ....7-24 to 7- 25
Receptacles. ....7-26 to 7-30
Receptacles for Microstrip....7-31 to 7-32
Hermetic Receptacles with Separate Glass Bead 7-33
Hermetic Receptacles with Intergrated Glass Bead 7-34
Hermetic Receptacles without Glass Bead. 7-35
Adapters....7-35 to 7-36
Accessories 7-36
Glass Beads 7-37
Accessories for Hermetic Microstrip Receptacles 7-38
Panel Drilling ....7-38 to 7-40
Tooling for Hermetic Receptacles 7-40
Field Replaceable Hermetic Microstrip Receptacle Information ....7-41 to 7-42

SMA-COM
Introduction. ....7-43 to 7-44
Interface. 7-45
Characteristics 7-46
Plugs ....7-47 to 7-48
Jacks ....7-48 to 7-49
Receptacles and Switches. ....7-50 to 7-52
Panel Drilling 7-52
Assembly Instructions ....7-53 to 7-54