Section 6 Table of Contents

SMB
Introduction..... 6-4 to 6-5
Interface. 6-6
Characteristics .....6-7 to 6-8
Plugs . .....6-8 to 6-11
Jacks . ..... 6-10 to 6-12
Bulkhead Jacks . ..... 6-12 to 6-14
Receptacles. ..... 6-14 to 6-15
PCB Receptacles. ..... 6-15 to 6-16
Adapters. 6-17
Panel Drilling 6-22
Assembly Instructions. 6-22

SMB-LOCK
Introduction. 6-18
Interface. 6-18
Characteristics 6-19
Plugs 6-20

SMB LIMITED DETENT (SMB-A)
Receptacles. 6-21

SMB SLIDE-ON (SUBGLIS)
Plugs and Receptacles.....6-21

SMC
Introduction. 6-23
Interface. 6-23
Characteristics 6-24
Plugs 6-25
Jacks . ..... 6-25 to 6-27
Receptacles.....6-27 to 6-28
Adapters. 6-28
Panel Drilling 6-28