

COAXIAL CABLE ASSEMBLY SELECTION LIST (CONT'D)

MINIATURE STACKING BANANA PLUG TO:

BNC MALE 144

MMCX PLUG RIGHT ANGLE TO:

MMCX PLUG 128

MMCX PLUG TO:

MMCX PLUG 128
128 MMCX PLUG RIGHT ANGLE 128
SMA MALE

N FEMALE BULKHEAD TO:

N MALE 34,82,83
N MALE RIGHT ANGLE 86
SMA MALE 34,72,73

N FEMALE TO:

N MALE 80,81,106,141
NMO MOUNT 255
QN MALE 84
QN MALE RIGHT ANGLE 85

N MALE RIGHT ANGLE TO:

N FEMALE BULKHEAD 86
N MALE 78,106,141
N MALE RIGHT ANGLE 79

7/16 DIN MALE 103
BNC MALE 51
GR874 100
MINI UHF MALE 107
N FEMALE 80,81,106,141
N FEMALE BULKHEAD 34,82,83
N MALE 29,33,76,77,106,141
N MALE RIGHT ANGLE 29,78,106,141
NMO MOUNT 255
QN MALE 84
QN MALE RIGHT ANGLE 85
REVERSE POLARITY SMA MALE 129
REVERSE POLARITY TNC MALE 131
SMA FEMALE 30
SMA MALE 30,33,74,75
TNC MALE 87

NMO (ANTENNA) MOUNTS TO:

BNC FEMALE 255
BNC MALE 255
JACK 255
FME PLUG 255
MINI UHF FEMALE 255
MINI UHF MALE 255
N FEMALE 255
N MALE 255
SMA FEMALE 254
SMA MALE 254
QN MALE TO: TNC 255
QN MALE TO: SMA 255
QN MALE TO: SMA MALE 55

QN MALE TO:

N FEMALE 84
N MALE 84
QN MALE 84

QN MALE RIGHT ANGLE TO:

N FEMALE 85
N MALE 85
QN MALE 85

QUICK DISCONNECT SMA MALE TO:

QUICK DISCONNECT SMA MALE 35
SMA MALE 35

REVERSE POLARITY MCX JACK BULKHEAD TO:

LFU 139

REVERSE POLARITY SMA FEMALE BULKHEAD TO:

LFU 139

REVERSE POLARITY SMA MALE TO:

BNC MALE 129
N MALE 129
SMA MALE 132
TNC MALE 132

REVERSE POLARITY TNC FEMALE BULKHEAD TO:

LFU 139

REVERSE POLARITY TNC MALE TO:

BNC MALE 131
N MALE 131
SMA MALE 130
TNC MALE

REVERSE THREAD SMA FEMALE BULKHEAD TO:

LFU 139

REVERSE THREAD SMA MALE TO:

REVERSE THREAD SMA MALE 133
SMA MALE

RCA FEMALE BULKHEAD TO:

RCA MALE 141

RCA MALE RIGHT ANGLE TO:

RCA MALE 141

RCA MALE TO:

RCA FEMALE BULKHEAD 141
RCA MALE 141

REAR MALE RIGHT ANGLE TO:

BNC MALE 144

SC MALE TO:

SC MALE 127

SHV PLUG TO:

MHV MALE 89
SHV PLUG

SMA FEMALE 2 HOLE PANEL MOUNT TO:

SMA FEMALE 2 HOLE PANEL MOUNT 70

SMA FEMALE 4 HOLE PANEL MOUNT TO:

SMA FEMALE 4 HOLE PANEL MOUNT 70

SMA FEMALE BULKHEAD TO:

LFU 139
SMA FEMALE BULKHEAD 69

SMA FEMALE TO:

SMA MALE 37,66,67
N MALE 30
NMO MOUNT 254

QMA MALE TO:

QMA MALE 55
SMA FEMALE

SMA MALE RIGHT ANGLE TO:

BNC MALE 53
SMA FEMALE BULKHEAD 37,66,67
SMA MALE 29,36,58,59
SMA MALE RIGHT ANGLE 37,60,61

SMA MALE TO:

1.85mm MALE 43
2.4 mm MALE 42
7/16 DIN MALE 104
BNC MALE 54
MC-CARD PLUG 136
MINI UHF MALE 107
MMCX PLUG 128
N FEMALE BULKHEAD 34,72,73
N MALE 30,33,74,75
NMO MOUNT 254
QMA MALE 55
REVERSE POLARITY SMA MALE 132
REVERSE POLARITY TNC MALE 130
REVERSE THREAD SMA MALE 133
SMA FEMALE 62,63
SMA FEMALE BULKHEAD 37,64,65
PUSH ON SMA MALE 30
SMA MALE 29,36,54,57
SMA MALE, PUSH ON 30
SMA MALE, QUICK DISCONNECT 30,35
SMA MALE RIGHT ANGLE 36,58,59
SMB PLUG 97
SMC PLUG 119
SMP FEMALE 135
SSMA MALE 125
TNC MALE 30,35,120,121

SMB JACK BULKHEAD TO:

SMB PLUG 95
SMB PLUG RIGHT ANGLE 96

SMB PLUG RIGHT ANGLE TO:

SMB JACK BULKHEAD 96
SMB PLUG 93
SMB PLUG RIGHT ANGLE 94

SMB PLUG TO:

BNC MALE 52
SMA MALE 97
SMB JACK BULKHEAD 95
SMB PLUG 92
SMB PLUG RIGHT ANGLE 93

SMC JACK BULKHEAD TO:

SMC PLUG 118
SMC PLUG RIGHT ANGLE 117

SMC PLUG RIGHT ANGLE TO:

SMC JACK BULKHEAD 117
SMC PLUG 115
SMC PLUG RIGHT ANGLE 116

SMC PLUG TO:

BNC MALE 52
SMA MALE 119
SMC JACK BULKHEAD 118
SMC PLUG 114
SMC PLUG RIGHT ANGLE 115

SMP FEMALE RIGHT ANGLE TO:

SMP FEMALE 135

SMP FEMALE TO:

SMA MALE 135
SMP FEMALE 135

SSMA FEMALE RIGHT ANGLE TO:

SSMA MALE 135

SSMA MALE TO:

SSMA MALE 125
SSMA MALE 125
SSMA MALE 125

SSMA MALE RIGHT ANGLE TO:

SSMA MALE 125

SSMA MALE TO:

SSMA MALE 125

SSMA MALE RIGHT ANGLE TO:

SSMA MALE 125

SSMA MALE TO:

SSMA MALE 125

SSMA MALE RIGHT ANGLE TO:

SSMA MALE 125

SSMA MALE TO:

SSMA MALE 125

SSMA MALE RIGHT ANGLE TO:

SSMA MALE 125

SSMA MALE TO:

SSMA MALE 125

SSMA MALE RIGHT ANGLE TO:

SSMA MALE 125

SSMA MALE TO:

SSMA MALE 125

SSMA MALE RIGHT ANGLE TO:

SSMA MALE 125

SSMA MALE TO:

SSMA MALE 125

SSMA MALE RIGHT ANGLE TO:

SSMA MALE 125

SSMA MALE TO:

SSMA MALE 125

SSMA MALE RIGHT ANGLE TO:

SSMA MALE 125

SSMA MALE TO:

SSMA MALE 125

SSMA MALE RIGHT ANGLE TO:

SSMA MALE 125

SSMA MALE TO:

SSMA MALE 125

Assemblies



+91 7217885948

www.rfconnector.in

pradeep@rfconnector.in



www.rfconnector.in